


BAND SWITCH




BAND SWITCH





TO CRYSTAL
P.C.B. (FIG.3.4)


CHANNEL
9 V
VARICAPS



MODE SWITCH



NOISE GENR.




MULTIVIBRATOR PCB

DC CONVERTER

VT29, VT30
VT44, VT45
(SEE FIG.3.2)

R	1, 2, 3, 4, 155
C	1, 2, 55,
D	18, 19,
VT	1, 2
MISC	FS1, FS2

NOTE: #030



TR28 B2 Circuit Diagram
Switch Functions and PCB Interconnections

Fig. 3.1

6, 7, 8, 9, 10, 11, 104, 105, 108, 125, 126, 127, RV9, RV11	109, 110, 111, 112, 113, 135, 136, 137	38, 86, 87, 88, 89, 114, 115, 116, 117, 118, 124, 128, 129, 130, 131, 139, 140	81, 82, 84, 85, 153, RV7	14
3, 4, 119, 120, 136	5, 6, 121, 122, 123, 125	7, 8, 9, 10, 11, 23, 57, 78, 79, 118, 124, 126, 140	12, 13, 80	14, 15, 16, 77
1, 2, 23, 29	44	43	20, 21	
3, 24, 25, 31, 32	26, 33, 34, 35	19, 27		
T1, T18	L1A, T2, T19	L1B, L1C	L1D, L1E, T3, T13	T4

